


MODEL #: TF150
150 WATT, 12 VOLT LANDSCAPE LIGHTING TRANSFORMER
FOR USE ON 120 VOLT CIRCUITS ONLY.
OUTDOOR RECEPTACLE SHOULD BE "GFCI" TYPE
NOT FOR USE WITH SUBMERSIBLE FIXTURES.

OPERATING INSTRUCTIONS


1. Plug in the transformer.
2. Make sure the transformer is located outdoors and would be exposed to sunlight.
3. Program the transformer by turning the dial to the desired setting (Fig. 1)

Settings:

- "OFF" - Power off
- "ON" - Power on, lights will stay on constantly.
- "AUTO" - Lights will turn on at sunset and turn off at sunrise. "Dusk to Dawn"
- "4H" - Lights will turn on at sunset and turn off 4 hours later.
- "6H" - Lights will turn on at sunset and turn off 6 hours later.
- "8H" - Lights will turn on at sunset and turn off 8 hours later.



TRANSFORMER DIAGRAM



WIRING DIAGRAM

