
STEP 1 - PLAN YOUR INSTALL

The TAPE-BT can be cut to fit the desired installation location. Carefully measure your space and plan how much of the TAPE-BT needs to be cut. For lengths longer than the provided TAPE-BT, you will want to add an additional TAPE-BT and cut off any excess. The LEDs in the TAPE- BT light up in 2 inch increments, so plan accordingly.




Carefully plan where the bt control box will be attached.

Do not bury the bt control box. Before installation, connect the TAPE-BT to a power source to ensure the bt control box can connect to the Alliance bt app and performs all of the desired app functions.




STEP 2 - CREATE A GUIDELINE

Create a guideline using either a straight edge and a pencil or a chalk line. Create a mark at every foot along the line to indicate where the brackets will be mounted.




STEP 3 - INSTALL BRACKETS

Using appropriate screws for the installation surface and either a screwdriver or a power drill, install the mounting brackets at the beginning of the tape-light run and then at every foot marker, finally install a mounting bracket at the end of the tape-light run.




STEP 4 - INSTALL TAPE-BT

Push the tape-bt into the mounting brackets, making sure the tape-bt is secured, taut, and straight.




STEP 5 - CONNECT

Trim the 10' wire lead as needed (make sure to leave 12" of slack in the wire) and connect to the power source using waterproof ALOC's.



STEP 6 - SECURE

Using a hammer to install the cable staples, secure the wire lead and bt control box to the installation surface.



Included in the Package:

A 1 - TAPE-BT



B 1 – Pre-installed control box



D Mounting Brackets and Screws



Additional Tools and Materials Needed:

ALOC Wire Connectors

Tape Measure







Wire Strippers



Screwdriver/Power Drill Chalk Line/Straight Edge



